

#86 INSTALLATION OF NEOPRENE VALVE COVER GASKET

PI-86

This high quality gasket will out last five of the original cork type gaskets, however for long life we recommend the following steps: 1) clean valve cover thoroughly with LACQUER THINNER or a cleaner that will NOT LEAVE RESIDUE, 2) use a good glue (rubber or weather cement [we use 3M YELLOW cement]) 3) glue the gasket to the valve cover. Let it stand long enough to take a GOOD SET before you install the valve cover, 4) install the valve cover---DO NOT OVERTIGHTEN the cover screws with this gasket as it will seal with less pressure than the cork gasket. Overtightening will cause the gasket to distort and leak.

NOTE...we recommend our #2k0143\* valve cover HOLD DOWN KIT for the steel valve covers  
\*(#2k0144 for 6 cyl)